

# Operation and Maintenance Manual

## PNEUMATIC DIAPHRAGM PUMP

# PD40SW



This manual contains important information on warnings and cautions. Read the manual thoroughly before starting to operate the pump, and follow the instructions.

Always keep the manual handy until such time as the pump is no longer being used.

If your manual is lost or worn badly, do not hesitate to contact our agency which is closest to you, or the Asahi Sunac Corporation, directly, and ask us to send you a new one.

*PNEUMATIC DIAPHRAGM PUMP*

# Thank you for buying our product.

Dear Valued Customer,

Thank you for buying our product, PD40SW.

Please read this manual carefully before starting to operate the pump. Please pay particular attention to major specifications, warnings and precautions, including prohibited items. Use the pump appropriately and with care, following the instructions. We hope that by doing so you win benefit from use of the product over a long period of time.

The pump is geared to industrial painting. It is for use only by those who are familiar with its workings and have undergone proper training; persons without such knowledge should not be allowed to operate the pump.

Should you have any questions with regard to the manual, please give us the "Model Name" and "Serial Number" of your equipment, so that we may be able help you with your questions. You can reach us at any of the addresses, phone numbers and fax numbers shown on the back cover.

Thank you,  
Asahi Sunac Corporation

## Contents



<b>1</b>	For Your Safety .....	1
<b>2</b>	Equipment specifications and components .....	4
<b>3</b>	Before You Start : General Precautions .....	5
<b>4</b>	Operation: Procedures and Precautions .....	6
<b>5</b>	Maintenance and Periodic Inspections .....	9
<b>6</b>	Useful Tips .....	9
<b>7</b>	Tear-Down Inspection and Replacement of Parts .....	10
<b>8</b>	Troubleshooting .....	13
<b>9</b>	Exploded Diagram and Part Names .....	15
<b>10</b>	Maintenance Log .....	18
<b>11</b>	Warranty .....	19

Please read and understand this manual. Always follow the instructions in it. Failure to do so may **result in injury to the user, or damage to equipment.**

The manual contains only minimum safety precautions and no implication is intended that other measures are unnecessary. Needless to say, regulatory and corporate safety rules and regulations must invariably be observed.

Shown below are minimum basic safety precautions in connection with use of our product:

● **The safety precautions are divided into three (3) categories, based on the degree of severity of the hazard:**

 <b>WARNING</b>	Indicates a potentially hazardous situation which, if not avoided by following the instructions given, could result in injury.
 <b>CAUTION</b>	Indicates a potentially hazardous situation which, if not avoided by following the instructions given, could result in damage or breakage of the equipment.
<b>NOTE</b>	Indicates general safety rules, including key practices and useful tips

※A potential hazard classified into the CAUTION category could still bring about serious results, depending on the circumstances. Always follow precautionary instructions issued to protect you and the equipment from potential injury or damage.

## **WARNING**

### **Potential Hazards: Misuse**

#### **<<General safety precautions>>**

- Never attempt to change component parts or modify the pump without prior consultation with Asahi Sunac. Any attempt to do so may result in equipment failure.
- Conduct periodic, and thorough inspections of the equipment, and repair and replace parts, as required.
- When spraying, ALWAYS use Personal Protective Equipment, such as protective goggles, working clothes, and/or means for breathing protection, as recommended by a manufacturers of paints or solvents. Depending on the chemical contents of the paint or solvent, and the ventilation system used, a different type of Personal Protective Equipment may be required. Please consult with the maker of the paint, or solvent concerned.
- Never leave the pump unattended while it is running. Keep children, and other unauthorized people well away from the painting equipment.

#### **<<Compatibility of paint and solvent>>**

Make sure that any fluid, any mixture of paint and solvent used, is chemically compatible with the material of the part of the pump with which it is likely to come into contact. Before use, carefully consider makers, and confirm whether or not it is compatible.

## WARNING

### Potential Hazards: Fires and Explosions

#### <<Sources of fires>>

As liquid paint flows through pumps and hose, static electricity is generated.

If painting equipment is not properly grounded, sparking may occur due to static electricity.

If sparks come into contact with spray paint particles, floating dust, or other inflammables the sparks could cause a fire or an explosion, possibly causing serious injury to the user and/or damage to the equipment.

- Provide good ventilation in the vicinity of spraying operations.
- Never conduct painting operations in the vicinity of source of a fire, a pilot lamp, or other inflammables.
- When cleaning the painting system,  
Always: Remove the nozzle, Point the tip of a spray gun at a grounded metal paint can, Keep part of the gun in contact with the can, and Pull the trigger for cleaning.
- Ensure that the painting equipment and workpiece are properly grounded. If they are not grounded, a fire or an explosion could result, caused by static electric discharge or sparking.
- Interrupt painting operations immediately if you feel static electric shock, no matter how slight it might be. Check the equipment for grounding. Do not resume operations until you clarify the cause, and take appropriate countermeasures.
- Always keep handy a powerful fire extinguisher in the spray painting area.

#### <<Grounding>>

To remove potential static electricity hazards, ensure that the pump, the workpiece, and all other items within the painting system (including other equipment in use near by) are grounded.

If you find something that is not properly grounded, ground it in accordance with the grounding methodology specified by Electrical Equipment Technical Standard (Class D or equivalent).

The grounding method for each item within the painting system is as follows:

- Pump  
Connect a ring crimp terminal (that comes with the equipment) to the pump grounding terminal (⊕), and then connect the other clip to a Class D grounding object.
- Air compressor  
Arrange the grounding in accordance with the maker's instructions.
- Painting hose  
Use a properly grounded hose. When using an extension hose, ensure that it is securely grounded.
- Spray gun  
A spray gun connected to a hose and pump that have been properly grounded, is itself deemed to be properly grounded.
- Workpieces  
Always remove dirt from hangers and grounding clips in order to keep workpieces grounded.
- Paint container  
Among paint containers, only those made of a conductive metal should be placed on a grounded floor or table. For details, refer to the local regulatory requirements, and comply with them.
- Cleaning solvent can  
Among the solvent cans, only those made of a conductive metal should be placed on a grounded floor or table. Do not place the conductive metal can on a non-conductive sheet, such as paper or corrugated fiberboard. Before you pull the trigger for cleaning the pump, or for reducing pressure, ensure that the metal portion of the gun is in contact with the grounded container, and securely supported.

## WARNING

### <<Solvents>>

- Never use a halogenated hydrocarbon solvent: When such a solvent comes into contact with an aluminum, or plated, portion of the painting equipment, it will react chemically in a way that is very dangerous.
- Further, such a solvent may explode upon coming into contact with an aluminum, or plated, portion of a pressure vessel (pump, heater, filter, valve, gun, etc.), on occasions leading to death or injury.

#### ● Some examples of halogenated hydrocarbon solvents

<b>Chlorines</b>	Trichloroethylene, Tetrachloroethylene, Ethylene chloride
<b>Bromines</b>	n-Propyl Bromide
<b>Carbon-fluorines</b>	HCFC-225, HFC-43-10mee, HFE-449s1(HFE-7100)

(Please note that the above examples do not cover all halogenated hydrocarbon solvents. Please contact a paint maker for further details.)

## WARNING

**In an atmosphere contaminated with paint- or spray-mist, you may suffer from respiration difficulties or you may even be intoxicated from organic solvents contained therein.**

- Do not use the painting system in a room, tunnel, tank, etc. where sufficient ventilation is not available. When you do use it, make sure that no people or livestock are within a vicinity where they may be affected.


# 2

## Equipment specifications and components

Model	PD40SW
Pressure ratio	1:2
Fluid displacement	60mL/cycle
Maximum output	15L/min (Liquid: water, per pump)
Normal flow rate ※	0.9L/min
Maximum air pressure	0.7MPa (Pump body, Max. intake air pressure: 1.0 Mpa)
Maximum paint outlet pressure	1.0MPa (at pump outlet)
Maximum fluid temperature	60°C
Noise	73dB/A (at 0.7MPa)
Air intake diameter	G1/4 (PF1/4)
Paint outlet diameter	G3/8 (PF3/8) (Low pressure regulator outlet diameter G3/8 (PF3/8))
Weight	15.0kg
Dimensions	690mm (H) x 470mm (W) x 640mm (L)

※ If you operate beyond the normal flow rate, the consumable parts may need replacement early.  
In addition, it may cause spray defect and abnormal parts wearing due to the cavitations depending on the kinds of paints.


### ● Pump output diagram (Pump only)



### ● Standard component parts

Pump body	1 set
Low pressure regulator	1 set
Air regulator	1 set
Increasing valve	1 set
Suction hose	1 set
Return hose	1 set
Stand	1 set

### ● Standard components and names of parts



※ A hexagonal bar wrench (6 mm) is included as a tool for assembling the stand. (Reference: P.6)

# 3

## Before You Start : General Precautions

- ① This diaphragm pump uses compressed air as a power source.  
The compressor should have a capacity of no smaller than 1.5KW (2ps)
- ② Power source air should be free of dust or impurities, which need to have been removed by means of air dryer or an air filter, etc.
- ③ When using oil-free air, in which oil has been removed by an oil-mist separator or a mist filter, be sure to install a lubricator \* (oiler) in the air supply line for continuous lubrication.

● Specified oil JIS K2213-Class 2

\* Lubricator (oiler) part No.: 302-0007

Similar to SAE-10	Turbine oil ISO VG32
Idemitsu Kosan	Daphne Turbine Oil 32
Cosmo	Cosmo Turbine Super 32
Showa Shell	Turbo Oil T32
JX Nippon Oil & Energy Corporation	Turbine Oil 32
Mobil	Mobil DTE Oil Light

- ④ Pressure drop may occur when a compressor is installed in a place far removed from where air is used.  
Arrange an optimum layout in, taking into accounts the compressor capacity and the place in which it is to be installed.

### NOTE

**For proper operation, the equipment requires a compressed air pressure of no less than 0.15MPa.**

- ⑤ The structure of this diaphragm is simple and not many parts are used. However, if you find that the pump is not functioning in the way it should be, or displaying symptoms of failure, make an adjustment or repair in accordance with "Tear Down Inspection and Parts Replacement (pages 9 – 11)" and "Troubleshooting (Pages 12 – 13)."  
Having done all this, if you find that the problem is still unresolved, do not try to do anything further on your own initiative, but rather call immediately our local agency, or Asahi Sunac directly for complete repair at our factory.
- ⑥ For a paint that deposits quickly, stir well before use, or use a stirrer.
- ⑦ Once a painting operation has been completed, you can either leave paint in the pump or remove it completely from the pump by means of cleaning. If you clean it, clean it completely. If you don't, just don't do anything. Leave it alone. In any case, do not clean the pump in a half-baked fashion. That is the worst thing you could do to the pump: the residual paint in the pump, left over from cleaning, would eventually harden, hampering suction capability and leading to a deterioration in painting performance.
- ⑧ Because of the way that the pump is constructed, no paint containing bone materials in it should be used.
- ⑨ Please note that, when using a paint with highly abrasive grains, such as a zinc-rich paint, there may be occasions where the life of ball, seat and diaphragm gets shorter than otherwise.
- ⑩ For the purpose of switching air, a snap-action type pilot valve is used for this pump. For this reason, when the pump stops at a stroke end (the right end or the left end), the pilot valve air will be continuously discharged. This does not mean that there is a failure, it is perfectly normal.

### CAUTION

**Please do not remove the suction filter. There is a possibility of the diaphragm damage by the foreign matter mixing when removing and using it.**


# 4

## Operation: Procedures and Precautions


### ① Unpacking, mounting and hooking up

The Diaphragm Pump Model PD40SW is ready for operation, and has been thoroughly inspected at the Asahi Sunac Plant. The only things you have to do is set up a stand and to connect a hose and gun, and you are all set to go. Having said that, when you receive shipment from us, you should inspect the equipment and parts immediately following unpacking, for they may have been subjected to vibration in transit. Check to see if there has been any damage to the equipment or parts or if any parts are missing. If you discover any damage or that parts are missing, please get in touch with our agency, or with Asahi Sunac direct.


- (1) Upon unpacking, check the equipment and parts against the packing slip  
For your reference, page 4 shows a typical packing slip with standard parts.
- (2) Assemble the stand.  
Follow these steps.



1. Insert the arm into the hole of the stand.



2. Insert the hex socket bolt and tighten using a hex wrench.



3. Secure the diaphragm pump and arm.  
Insert the flat washer, spring washer and hexagon socket head cap screw and tighten them using a hexagon bar wrench.

- (3) Attach the low pressure regulator securely to the paint outlet joint referring to the picture on page 4.
- (4) Hook up the paint hose to the paint outlet of the low pressure regulator, and then the spray gun to the hose.
- (5) Turn the air regulator handle counterclockwise, loosening it to the maximum extent possible.

### ② Method of operation

Clean the inside of the equipment with solvent (cleansing thinner). Operate each function to check that if everything is OK.

## ⚠ WARNING

**Check the paint passage for leaks. If you find any leak, turn the air regulator handle counterclockwise immediately, shutting off the air pressure. Then re-tighten the joint at which you have noticed the leak.**

## ⚠ CAUTION

**When you use thinner, turn on the ventilator.**

If you find foreign matters in solvent, remove it. Foreign matters inside the pump will cause clogging and painting failure. Please follow the following procedure to prepare for operations.

- (1) Pour around 3 liters of solvent into a paint can (container). And put the suction member into it.
- (2) Open the ball cock.  
Slowly turn the air regulator handle clockwise (open). As compressed air starts coming in, the pump will be set in motion. Let solvent discharge from the return hose for two to three minutes. Then, shut off the ball cock.

 **CAUTION**

**In order to prevent an air regulator from getting damage, unlock the handle of air regulator before operate.**

 **CAUTION**

**Set the air regulator at about 0.1 MPa.**

- (3) Point the spray gun into the paint can and pull the trigger. As solvent runs through the pump and paint hose, it will take any air with it along the way, making them air-free inside (air will be discharged as bubbles). Once cleaning has been completed, pull off the suction member. Open the ball cock, letting the pump run idly, removing all remaining solvent through the return hose. Close the air regulator by turning the handle counterclockwise. The above constitutes the setting up of equipment for a painting operation.

**③ Operating procedure**

- (1) Pour paint into a paint container.
- (2) Open the ball cock.
- (3) Slowly open the air regulator by turning the handle clockwise, setting the pump in motion.

**NOTE**

**Set the air regulator at about 0.1MPa.**

- (4) When paint comes out of the return pipe, close the ball cock.
- (5) Set the air regulator to an operating pressure.  
Also set the low pressure regulator to an operating pressure -- by turning the handle clockwise until the regulator opens to the extent that is just right for the operating pressure.

**NOTE**

**Recommended pressure setting for normal operations:  
Air regulator at 0.3MPa or more: Low pressure regulator at 0.1~0.15MPa**

When paint viscosity is high or when you want to feed paint at a higher rate, set the air regulator to a pressure higher than normal.

 **CAUTION**

- ① **Air purging or pressured paint feeding from the suction side of PD40SW, the paint may enter the air chamber and the pump may stop.  
When performing air purging or pressured paint from the suction side, set the pressure to 0.02MPa or less.**
- ② **When paint supply runs out in the middle of operation, the system sucks air in place of paint and paint spraying operation will be disrupted with the pump running idly.  
After lowering the air pressure of the air regulator and replenishing the paint, bleed the air from the ball cock and gun, and restore the pressure setting before starting work.**

#### ④ Interrupting operation

- (1) Close the air regulator by turning the handle (counterclockwise) and stop the pump.
- (2) Make sure that air pressure is removed from the ball cock and gun.

### **WARNING**

**Paint may flow backward, so relieve pressure from the ball cock or gun tip when operation is interrupted.  
If pressure cannot be released at line, take measures such as placing a check valve to prevent backflow.**

### **CAUTION**

**When you start a diaphragm pump for the first time in a day, or when you shut it down at the end of the day's work, use the air regulator – open for starting up and close for shutting it down. Never start the compressor with the diaphragm compressor regulator valve open: should you do so, the air valve might fail, causing the pump to fail.**

#### ⑤ Changing paint colors and cleaning

- (1) Open the ball cock. Remove the suction filter from the paint can.  
Run the pump without a load to expel any paint that has remained inside the pump. Close the ball cock.  
Pull the trigger of the spray gun, expelling any paint that has remained inside the hose.
- (2) Once paint has been expelled from the system, put the suction member into the cleansing liquid tank.  
Open the ball cock to circulate cleansing liquid for flushing.

#### ⑥ Post-operation procedure

Having interrupted operation following the procedure as per ④, there are two kinds of post-operation procedures, (1) and (2), to choose from depending on the shutdown period and type of paint used.

### **WARNING**

**Always see to it that air pressure is removed from the ball cock and gun: failure to do so may cause paint to flow in a reversed direction.**

**Paint may flow backward, so relieve pressure from the ball cock or gun tip when operation is finished.**

**If pressure cannot be released at line, take measures such as placing a check valve to prevent backflow.**

- (1) Leave the system filled with paint.  
Because no air is trapped in the paint passage, oil is kept in the system as if it were being kept in a paint can for storage, thus preserving it free from solidification. However, if the kind of paint you are using is one that deposits quickly, such as a two-component paint, do not keep it in the system too long. You would be better off following Procedure (2).
- (2) Keep the system paint-free.  
Flush the system with cleansing solvent, thoroughly: paint, if left out, will deposit and solidify with time, no matter how small the amount is. Keep the system filled with cleansing solvent until you use the system again.

### **CAUTION**

**However, when you shut down the system for a long period of time, after flushing with water, you should also flush the system with an organic solvent. When the period of shut down is over, fill the system again with organic solvent.**

# 5

## Maintenance and Periodic Inspections


### ① Maintenance

- (1) Daily maintenance operations  
Cleaning of gun and suction filter
- (2) 100-hour maintenance operations  
Cleaning of pump and low pressure regulator
- (3) 1000-hour maintenance operations  
Inspection of diaphragm, ball and valve seat

### ② Perishable parts replacement frequency

#### (1) Wet parts

Replacement frequency based on typical discharge rate at 1 liter per minute (Valve shifting clicking sound every 2 seconds)



The numbers of parts are taken from the lists of parts in this manual.

Unit: hour

Index number	Part No.	Part name	Standard paint	Abrasive paint (ceramics, zinc, etc.)
16-6	3714-006	Diaphragm	3000 - 5000	1000 - 2000
16-16	3714-016	Seat	3000 - 5000	500 - 1000
16-17	3717-017	Valve seat	5000 - 10000	1000 - 2000
16-18	3701-022	Ball (discharge)	2000 - 4000	500 - 1000
16-18	3701-022	Ball (suction)	5000 - 10000	1000 - 2000

When changing valve seats, change O-rings (101-6012, 101-6014), as well.

#### (2) Air valve replacement parts

The numbers of parts are taken from the lists of parts in this manual.

Unit: hour

Index number	Part No.	Part name	Unlubricated	Lubricated
16-9	3711-009	Slider	10000	10000
16-13	3711-013	Bushing	10000	10000
16-23	314-0015	Air valve	3000	10000
16-26	130-6014	O-ring	3000	10000

The maintenance schedule described above is based on normal operating conditions. Depending on the frequency of color change, paints used, and pressure setting, the inspection and frequency of replacement of parts may vary: use your own discretion for appropriate frequency.

When you use this device at a flow rate of 2L/min or more, we recommend that you use the tanked boost valve (PN:399F) together. According to replacement time of increasing valve, refer to manufacturer's manual of that. Please contact us about order or installation.

The parts marked with ※ are perishable parts, and we recommend that you carry an inventory at all times.

# 6

## Useful Tips

When using a kind of paint that quickly deposits, such as a metallic paint, etc... slightly open the ball cock for stirring the paint, making use of short circulation.

# 7

## Tear Down Inspection and Part Replacement of Parts


Inspect periodically diaphragms, balls, and valve seats, etc.

When you discover excessive wear or fatigue, replace the parts in accordance with the procedures shown below. Before you get down to inspection or replacement of parts, clean the pump thoroughly. And then take the parts apart.


### CAUTION

**Tear down inspection and replacement of parts should be carried out only by those who are well acquainted with the ways in which they should be conducted, and strictly follow the procedures designated.**


#### ① Inspection and replacement: Suction valve, ball, and valve seat



① Remove the valve seat with a 27mm spanner. There is one for each side, Left side and Right side.




② Check the ball for deposition of foreign matter (paint, etc.), damage, and wear (see if diameter is too small in relation to normal ball diameter, 14.2mm). Replace, as required.




③ Check valve seat for deposits (paint, etc.) on paint passage and for damage on seat surface. If there is a deposit, clean. If there is minor damage, polish with #400 water-proof emery paper. (Polish uniformly all round). If damage is too extensive to repair, replace.


#### ② Inspection and replacement: Discharge valve, ball, and seat



① Remove flange mounting screws and the flange will come off the pump body. Remove both Left side and Right side flanges.



② Remove manifold from flange.




③ Push ball from one end with pencil or stick. Seat at the other end will come off with the ball. Put the ball in from the end where seat just came off and push it with a pencil or stick. Seat at opposite end will come off.


### ③ Inspection and replacement: Diaphragm

#### Removing the diaphragm


Remove flanges in accordance with the procedures per ① and ② for check valve inspection and replacement. Now, you are ready for diaphragm inspection. Check it for damage, cracks, etc.




① Using two spanners on M6 nuts on both sides, remove one of the nuts.




② Remove the disk, the diaphragm, and then the other disk from the side from which you have removed the nut.



③ Remove the diaphragm on the opposite side together with the shaft.




④ Put a spanner over the two opposing flat faces of the shaft nut and turn it to remove the nut.




⑤ Remove the disk, then the diaphragm, and then the other disk.


#### Attaching Diaphragm




⑥ Mount parts onto the shaft in the following order: Disk, O-ring, diaphragm, other O-ring, then disk. After that, mount the spring washer and M6 nut, which for the time being should then be tightened lightly.



⑦ Put the diaphragm as assembled on the shaft onto one side of the pump body. Then, from the other side, install parts in the following order: disk, O-ring, diaphragm, other O-ring, disk spring washer, and nut. When installing the diaphragm, make sure that the diaphragm sphere is facing the outer side.



⑧ Tighten nuts with two spanners. (Tightening torque:  $1000\text{N} \cdot \text{cm}$ ) If tightening torque is not proper, trouble may result, such as a fluid flowing into the air passage.



⑨ To finish assembling, mount both (Left side and Right side) flanges. (Tightening torque:  $3000\text{N} \cdot \text{cm}$ ) If tightening torque is not proper, fluid may leak from the flange portion.

#### ④ Inspection and replacement: Pilot valve (slider)

※Conduct an inspection only when the pump has failed.

(1) When a malfunction has occurred in the air valve (16-23), first make sure whether the air valve is operating or not.

Open the air regulator again by moving air valve control from side to side and supply compressed air.

When the slide control is too heavy, or when there is leak from mufflers (16-19) all the time, replace.

(2) When there is a continuous air leak from the muffler (16-7) on either side of the manifold (16-4) (on which the air valve is mounted), or when the air valve (16-23) frequently fails, wear of pilot valve may be suspected. Inspect and repair in accordance with the following procedures:

- ① Shut off supply of the air to the air intake.
- ② Remove the diaphragm in accordance with the diaphragm inspection and replacement procedure (page 10).
- ③ Remove the housing (16-14), and replace the O-ring (16-26) within housing.
- ④ Remove the housing (16-14), and pull out of the shaft (16-10).
- ⑤ Replace the slider (16-9) located in the middle of the shaft (16-10) that has been pulled out.

Apply grease to the shaft (16-10), the slider (16-9), and the collar (16-11). And then, put them back on.

\* A set of two numbers connected with a hyphen in parentheses ( ) represents the page number on which the part is shown (the number before the hyphen), as well as the index number of the same part (the number after the hyphen) appearing on that page.

# 8

## Troubleshooting

A set of two numbers connected with a hyphen in parentheses ( ) represents the page number on which the part is shown (the number before the hyphen) as well as the index number of the same part (the number after the hyphen) appearing on that page.

Symptom	Probable cause	Remedy
<b>1. Paint pressure does not go up.</b>	①Failure to open air regulator (15-9)	①Open completely (clockwise).
	②Defective pressure gauge (15-12)	②Replace it with a new one.
	③Hardened paint on ball (16-18) in pump due to insufficient post-operation cleaning	③Thoroughly clean with thinner. If it does not work, take pump apart and clean.
	④Air valve (16-23) failure	④Move air valve slide control from side to side. If it does not work after repeated attempts, replace.
<b>2. No paint discharge, even when pump is still operating</b>	①Clogged suction filter (15-8)	①Clean suction filter screen (17-3).
	②Ball (16-18) stuck to seat (16-16) or valve seat (16-17), and will not detach.	②Clean seat (16-16) and valve seat (16-17)
<b>3. Paint discharge tapering off</b>	①Clogged suction filter (15-8)	①Clean suction filter screen (17-3).
	②Clogged low pressure regulator (15-9)	②Take low pressure regulator apart and remove foreign matter by cleaning.
	③Clogged paint passage	③Take it apart and clean.
<b>4. Pump does not run at uniform rate</b>	①Clogged suction filter (15-8)	①Clean suction filter screen (16-3).
	②Defective slider (16-9) seat, with continuous air leak from muffler (16-7)	②Take slider apart and clean. If you find damage on slider (16-9), replace.
<b>5. Pump failing to come to a stop after spraying has stopped</b>	①Empty paint can (container)	①Replenish paint.
	②Leak from pain passage	②Bring paint fluid pressure down to zero by turning air regulator counterclockwise, then retighten socket head cap screw with washer (16-32). (Tightening torque: 3000N · cm)
	③Defective seat (16-16) or valve seat (16-17)	③Clean or replace seat or valve seat.
<b>6. Air leak from muffler (16-7)</b>	①Defective slider (16-9)	①Take slider (16-9) apart and clean. If you find damage or wear on sealed portion (black portion) of slider, replace.
	②Excessive wear of O-ring (16-26) within housing	②Replace O-ring.

Symptom	Probable cause	Remedy
<b>7. Air gets in from outlet</b>	①Broken diaphragm (16-6)	①Replace diaphragm. When there is paint deep inside the air valve, clean the paint passage, thoroughly dry, and then replace the air valve (16-23).
	②Hexagonal nuts (16-36) of disks (16-15) that hold diaphragm from sides, loose	②Tighten hexagonal nuts. If there is a paint leak from the exhaust muffler, replace the air valve (16-23).
	③Flange (16-2, 16-3)- mounting hexagonal socket screws (16-32) loose	③Tighten hexagonal socket screws. (Tightening torque: 3000N · cm)
<b>8. Paint leak from the pilot exhaust</b>	①Housing O-ring (16-26) consumption.	①Replace the O-ring
	②Slider(16-9) consumption	②Replace the Slider
<b>9. Paint pressure of Air regulator does not go up at 1.0MPa</b>	①Too much flow rate	①Reduce the flow rate Go up the circulation flow rate
	②Primary air pressure is less than 0.6MPa (Pressure gage of increasing valve at bottom is less than 0.6MPa)	②Increase the primary air pressure
	③Setting of increasing valve pressure is low	③Turn the handle of increasing valve at top with clockwise up to 1.2MPa.

#### Low pressure regulator

Symptom	Probable cause	Remedy
<b>Paint pressure does not go up</b>	①Clogged fluid passage	①Take it apart and clean.
	②Defective pressure gauge (13)	②Replace pressure gauge. (13)
<b>Paint pressure does not come down</b>	①Foreign materials on valve seat (5)	①Detach the valve (5) and remove foreign objects by air blow.
	②Worn valve (5)	②Replace valve (5).
<b>Paint leaks from regulator handle</b>	Broken diaphragm (4)	Replace diaphragm
<b>Paint pressure fluctuates</b>	Pump pressure too low	Set pressure higher (0.15~0.7MPa).


NOTE: Due to continuous improvements and modifications, the configurations and specifications of the equipment specified herein are subject to change without prior notice.

# 9

## Exploded Diagram and Names of Parts

PD40SW

40363-1



Diaphragm pump <40363-1>

No.	Part number	Part name	Qty	Remarks
1	3714	Diaphragm pump	1set	
2	1954-5	Stand	1set	
2-1	1954-501	Stand	1	
2-2	1954-102	Handle	1	
2-3	1954-503	Arm	1	
3	40391-003	Manifold	1	
3-1	155-2010A	Back-up ring	1	※1
4	287-2002	Hose joint	1	
5	247-4202	Hose joint	1	
6	0769-1	AR70SW Low pressure regulator	1	
7	5611-1	Suction hose	1set	※2
8	0520	Suction filter	1set	
9	301-0071	Air regulator	1	
10	325-0047	Ball cock	1	
11	40363-012	Air tube	1	
12	305-0050	Pressure gauge	1	
13	03-80815	Hex. socket bolt	6	※3
14	37-10800	Plain washer	2	

No.	Part number	Part name	Qty	Remarks
15	68-10410	Screw	1	
16	40338-024	Ground wire	1	
17	41-80800	Spring washer	2	
18	40332-021	Pipe holder	1	
19	15-11000	Hex. nut	1	
20	10-61030	Wing bolt	1	
21	3444-2	Return hose	1set	
21-1	40332-501	Return pipe	1	
21-2	201-4002	Elbow	1	
21-3	244-4001	Hex. socket plug	1	
21-4	3213-009	Hose joint	1	
21-5	342-0122	Volute nipple	1	
21-6	595-0008	IRRAX hose	1	
22	334-0060	Hex. wrench	1	
23	314-0031	Increasing valve	1	
24	3201-029	Hose joint	1	
25	40363-031	Name Plate	1	


※1. No. 3-1 Backup ring is an accessory of No. 3 Manifold.

※2. If you need a hose only, please order No. 52A-0008.

※3. 2 pcs of the No. 13 hexagon socket head cap screws are accessories for No. 2 stand.

## Diaphragm pump body

### 3714



### Diaphragm pump body PD40SW <3714>


No.	Part number	Part name	Qty	Remarks
1	3714-001	Body	1	
2	3714-002	Flange	1	
3	3714-003	Flange	1	
4	3711-004	Manifold	1	
5	3714-005	Manifold	1	
6	3714-006	Diaphragm	2	
7	3711-007	Muffer	2	
8	3711-008	Packing	1	
※9	3711-009	Slider	1	
10	3711-010	Shaft	1	
11	3711-011	Collar	1	
12	3711-012	Guide	1	
13	3711-013	Bushing	2	
14	3711-014	Housing	2	
15	3711-015	Disk	4	
16	3714-016	Seat	2	
17	3714-017	Valve seat	2	
18	3701-022	Ball	3	
19	3701-014	Muffer	2	

No.	Part number	Part name	Qty	Remarks
20	3701-024	Filter	2	
21	3714-021	Manifold	1	
22	344-0004	Quick joint	1	
23	314-0015	Air valve	1	
24	130-6007	O-ring	1	
25	130-6022	O-ring	2	
26	130-6014	O-ring	2	
27	130-6025	O-ring	2	
28	101-6012	O-ring	4	
29	101-6006	O-ring	4	
30	101-6021	O-ring	4	
31	3701-041	Long nipple	1	
32	1F-80835	Hex. socket bolt	10	
33	41-70600	Spring washer	2	
34	12-10312	Two-point sems screw	4	
35	03-80408	Hex. socket screw	6	
36	15-70600	Hex. nut	2	
38	101-6014	O-ring	2	

※ When ordering a Slider (Index No. 9), please also order O-ring (index No. 24) as well.


### Low pressure regulator

**0769-1**



### Suction filter

**0520**



#### Low pressure regulator AR70SW <0769-1>

No.	Part number	Part name	Qty	Remarks
1	0767-001	Housing	1	
2	0740-007	Spring retainer	1	
3	0767-003	Body	1	
◆4	0767-004	Diaphragm	1	
◆5	0776-105	Valve	1	
◆6	101-2007	O-ring	1	
7	0767-007	Gasket	1	
8	0740-014	Spring	1	
9	17-11000	Hex. nut	1	
10	322-0069	Handle	1	Blue
11	03-70414	Hex socket bolt	6	
12	0741-025	Gauge fixing nipple	1	
13	305-0052	Pressure gauge	1	
14	247-4203	Elbow union	1	

• Items marked with ◆ are those items that we recommend you carry in your stock.

※ When replacing the valve, replace the No. 6 O-ring as well.

#### Suction filter SF903S <0520>

No.	Part number	Part name	Qty	Remarks
1	0501-001	Filter body	1	1
2	0501-002	Snap	1	2
3	0511-003-06	Screen	1 set	60 mesh



ASAHI SUNAC CORPORATION (the “Company”) shall provide the original purchaser (the “Purchaser”) with warranty service for a period of one (1) year from the date of purchase of the product, as follows:

- Should you find defects in design or workmanship with regard to parts, ship them back to the Company, with freight prepaid. The Company shall repair or replace the parts free of charge and reimburse the freight charges, provided that, as a result of an inspection and investigation of the parts conducted by the Company, the defects are deemed to be attributable to the factors within the Company’s responsibility.
- In the following cases, free after-sales service is not provided.
  1. Failure resulting from an inappropriate method of installing this equipment.
  2. Failure resulting from a use method not conforming to this instruction manual or mishandling.
  3. Failure resulting from insufficient maintenance management of this equipment and incorrect handling such as non-conformance to the procedures specified in this instruction manual.
  4. Failure resulting from unauthorized alteration or structure change of this equipment without the Company’s consent.
  5. Failure due to force majeure such as earthquake, disaster, flood disaster or lightning.
  6. Warranty for consumables worn or deteriorated even in the case where this equipment is used correctly.
  7. Repair after the machine has been used outside Japan, and shipping cost.
  8. In addition to the above, failure due to circumstances beyond our control.
- As for items such as parts purchased by the Company from another manufacturer, the warranty of that manufacturer shall apply.
- As for any parts deemed to be defective, the Company shall not be held liable for any expenses beyond the provision of repair or replacement parts free of charge.
- The Company shall not be held liable for any damage to the Purchaser caused by factors not attributable to the Company, such as misuse of product, etc.

【MEMO】



- 
- When a transfer of title of this equipment takes place, please see to it that this Operation and Maintenance Manual is handed over to the new owner.
  - This equipment is manufactured in compliance with the Laws and Regulations of Japan. In the rare eventuality of this equipment being used outside Japan, compliance with the safety standards of the relevant countries is of course mandatory.
- 

32th Edition: July 1, 2022

## ASAHI SUNAC CORPORATION

### HEAD OFFICE

5050, SHINDENBORA, ASAHIMAE-CHO,  
OWARIASAH, AICHI PREF. 488-0852, JAPAN  
PHONE +81-561-52-0717 FAX +81-561-54-8847

URL : [www.sunac.co.jp](http://www.sunac.co.jp)  
E-mail : [ctrd01@sunac.co.jp](mailto:ctrd01@sunac.co.jp)

### Sales office

---



English



Chinese

32th Edition: July 1, 2022