

Operation and Maintenance Manual

Air Electrostatic Handgun

HB6000



This manual contains important information on warnings and cautions. Read the manual thoroughly before starting to operate the equipment, and follow the instructions.

Always keep the manual handy until such time as the product is no longer being used. If your manual is lost or worn badly, do not hesitate to contact our agency which is closest to you, or Asahi Sunac Corporation directly, and ask us to send you a new one.

Introduction

Thank you for purchasing our product air electrostatic handgun < HB6000>.

Please be sure to read this operation manual carefully before using this product so that you can always use it under the optimum conditions.

In particular, please fully understand the items in the specifications and use them according to the correct usage.

This product is used in combination with the electrostatic controller (BPS130EN) or (BPS1600).

Be sure to read the operation manual of the electrostatic controller carefully.

If you have any questions, please contact us by clearly stating the "product number" and "serial number" and contacting us on the back cover.



Please keep this operation manual in a safe place where you can easily refer to it.

Contents	
1	FOR SAFE AND CORRECT USE..... 1
2	OUTLINE OF EQUIPMENT..... 6
	2.1 Names and Roles of Parts..... 6
	2.2 Structure Example of Coating Machine Installation..... 7
	2.3 Related Accessory Equipment..... 8
	2.3.1 Air Cap (Model: HN Series) (Separately Offered) 8
	2.3.2 Electrostatic Controller (BPS130EN) 8
	2.3.3 Transmission Cable..... 9
	2.3.4 Air Hose (Model: AH22 Series) 9
	2.3.5 Paint Hose..... 10
	2.3.6 Maintenance Tool Set..... 10
3	SPECIFICATIONS..... 11
	3.1 Dimensional Outline..... 11
	3.2 Product Specifications..... 11
	3.3 Specific conditions of use..... 11
4	UNIT INSTALLATION..... 12
	4.1 Connection of Air Source..... 12
	4.2 Connection of Grounding Wire..... 12
	4.3 Transmission Cable..... 12
	4.4 Connection of Air Hose..... 13
	4.5 Connection of Paint Hose..... 14
	4.6 Bundling of Connecting Cable and Precautions for Use..... 15
	4.7 Installation of Air Cap..... 16
5	CHECK BEFORE COATING OPERATION..... 17
	5.1 Operation Check at High Voltage..... 17
	5.2 Mixing of Paint..... 17
6	COATING PREPARATION..... 18
7	PAINT..... 20
8	MAINTENANCE AND INSPECTION..... 21
	8.1 Measures After Operation is Completed..... 21
	8.1.1 In Case Where Operation is Resumed Within 24 Hours..... 21
	8.1.2 In Case Where Operation is Not Performed for 24 Hours or More..... 24
	8.2 Periodic Inspection..... 25
	8.3 Consumables..... 28
9	PAINT PROBLEMS AND SOLUTIONS..... 29
10	TROUBLESHOOTING..... 31

11	PARTS REPLACEMENT METHOD	33
	11.1 Replacement of Air Cap.....	33
	11.2 Replacement of Paint Nozzle Assembly.....	33
	11.3 Replacement of Ground Electrode Assembly.....	34
	11.4 Replacement of Packing Assembly.....	34
	11.5 Replacement of Needle Assembly.....	35
	11.6 Replacement of Pattern Valve.....	35
	11.7 Replacement of Paint Adjuster.....	36
	11.8 Replacement of Air Valve Assembly.....	36
	11.9 Replacement of Grip End Assembly.....	37
	11.10 Replacement of Gun Hook.....	37
	11.11 Replacement of U Seal (373-0008).....	38
	11.12 Replacement of Paint Tube.....	39
	11.13 Replacement of Electrode Assembly.....	39
12	COMPONENT	40
	12.1 HB6000.....	40
	12.2 HB6000 Core Unit.....	41
	12.3 Replacement Parts.....	42
13	MAINTENANCE LOG	45
14	WARRANTY	46

Please understand the contents of this instruction manual and be sure to follow the handling method. If you use it without following this instruction manual, **you may injure your body or damage your equipment and fire.**

The following safety precautions should be considered as minimum basic safety measures when using our products.

● **Precautions are displayed in the following two stages.**



WARNING

Hazards that can result in death or serious injury.



CAUTION

Danger that may result in minor or moderate injury or physical damage only.

● **Other important points are indicated as follows:**

NOTE

Observations to ensure the equipment's performance and functions are fully operational.

In addition, please observe all national and local laws and regulations related to fire, electricity, and safety, as well as the rules and regulations of your own company or business division.

« **Range of use suitable for the product** »

This product is a manual spray gun designed to be installed in the coating booth equipped with an exhaust system and used for painting with air electrostatic atomization paint.

If you use the product under conditions other than the above, it will be used improperly. Also, please be careful as it may cause an accident.

 **WARNING**

Fire and explosion



Preventing fire and explosion in coating shop

- **Do not use halogenated hydrocarbon solvents.**
The aluminum alloy contained in this product's components may undergo a chemical reaction and explode.
- **Do not use this product outside its specifications.**
Using it out of specification range may result in a fire hazard.
- **Provide adequate ventilation with ventilation equipment.**
Volatilized organic solvents and other substances may remain and ignite, creating a risk of fire.
- **Clean the coating room and exhaust system (ducts and fans) regularly.**
If the accumulated powder simply peels off, a spark may occur, which could cause a dust explosion.
In the unlikely event of a fire, paint residue etc. will make it easier for the fire to spread and result in greater damage.



Prevent fire and electric shock caused by faulty earthing

- **All conductive objects in the coating booth (paint containers, peripheral equipment, etc.) must be grounded with an earth wire.**
In an atmosphere ionized by high voltage, poorly grounded conductors can become charged, creating a risk of fire or electric shock due to spark discharge.
The earth should be **Class D grounding or higher** (ground resistance 100 Ω or less).
- **Always keep the workpiece earthed.**
Risk of fire or electric shock due to spark discharge from charged workpieces.
- **Paint hose must be grounded with an earth wire.**
Static electricity can cause spark discharge, which can result in fire or electric shock.
When paint flows through the injector and paint hose, static electricity is generated and becomes charged.
- **The paint container must be grounded with an earth wire (excluding the insulated stand specifications).**
The paint path can cause the paint container to become charged, a risk of fire or electric shock.
- **The electrostatic controller must be grounded with an earth wire.**
Static electricity can cause spark discharge, which can result in fire or electric shock.
The machine is also grounded via the electrostatic controller, so be sure to connect the earth wire with screws or other fasteners to prevent it from coming loose.

《Warning and precautions for safe use》

 **WARNING**

Fire and explosion



Prevent fire and electric shock caused by faulty earthing

- **Be sure to periodically remove any paint that has stuck to the hanger.**
If paint adheres to the contact part between the hanger and the object, there is a risk of fire or electric shock due to poor earthing.
The ground resistance value should be 1kΩ or less for metal (1MΩ or less for resin) (measurement voltage should be 500V or more).
- **Do not place any items in the coating booth that are not necessary for coating.**
Static electricity can cause spark discharge, which can result in fire or electric shock.
- **Paint operator must take precautions to prevent static electricity.**
Static electricity builds up on the human body, causing sparks to discharge, which may result in fire or electric shock.



Prevent fires caused by ignition of paints and solvents

- **When nozzle cleaning, turn off the power to the electrostatic controller.**
If high voltage is applied during nozzle cleaning, there is a risk of fire.
- **Do not bring any spark-producing devices, matches, lighters, etc.**
Risk of explosion or fire due to ignition of flammable materials.

Equipment misuse



Preventing accidents caused by poor maintenance

- **Any abnormal noise, vibration or high voltage leakage, immediately stop operation.**
Product damage may result in a fire hazard.
- **Do not operate if any parts are damaged or missing.**
Product damage may result in a fire hazard.

 **WARNING**

Human protection



Protection from high voltage

- **Please wear anti-static shoes.**
Static electricity builds up on the human body, causing sparks to discharge which may result in fire or electric shock.
- **Do not touch anything other than the gun grip while high voltage is applied.**
Touch with high voltage parts may result in electric shock.
- **The coating work floor must have an anti-static construction with a leakage resistance of 1 MΩ or less.**
There is a risk of electric shock to the operator.
The scope of the antistatic structure is the entire work floor in a closed paint room.
In an open paint booth, it is the area surrounded by 1.5m on either side of the booth opening and 2.5m in front of it.
To maintain the antistatic effect, clean the work floor when it becomes dirty.
- **Do not use this product if you have a pacemaker.**
The high voltage of this product may cause pacemakers to malfunction or stop functioning.




Protection from solvents, air and paint pressure

- **Do not spray paint towards person**
Harmful substances may cause serious injury, including inflammation and poisoning.
Pressurized paint can cause personal injury.
- **Wear protective glasses, a protective mask, and protective gloves*¹ when handling paint.**
Harmful substances may cause serious injury, such as inflammation or poisoning.
Carefully read the safety data sheet (SDS*²) of the paint you are using and take appropriate exposure prevention and protective measures.
*¹ When using protective gloves for skin absorption protection or to prevent dirt, it is necessary to prevent static electricity from building up on the human body.
Be sure to ground it properly. (Recommended protective gloves are those specified in JIS T8118, or earth bands, etc.)
*² SDS : Safety Data Sheet
- **Clean the coating room and exhaust device (ducts and fans) regularly.**
If the exhaust device does not function properly, harmful substances may cause serious injury, including inflammation and poisoning.

《Warning and precautions for safe use》

WARNING

- **Do not use this product outside its specifications.**
Using it out of specification range may result damage to the product.
- **Do not immerse the coating machine, connection/extension cable or hoses in cleaning solvent.**
Electrostatic sprayer are electrical machines, immersing them in cleaning solvents may cause break down.
- **Connection/extension cable and hose should be hung from the ceiling or side walls and not dragged across the floor.**
It may cause damage such as scratches.
When using conductive paint, be sure to suspend the paint hose from an insulating material such as a rubber tube.
- **When cleaning the nozzle, never use a metal brush, use a bamboo brush or similar.**
It may damage the nozzle and result in poor coating.
The nozzle is an important part of the sprayer.
If you use a metal brush to damage the nozzle, it will become difficult to maintain uniform spray conditions.
- **Always keep a distance of at least 150mm between the tip of the nozzle and the work piece.**
The potential at the tip of the nozzle will decrease, causing poor coating results.
- **Check frequently for paint leaks, air leaks, and loose screw.**
- **Do not touch the electrode pins of the spray gun carelessly.**
The electrode pin may pierce the body and cause injury.
Be careful when handling the electrode pin as they are easily pierced.




- **A fire extinguisher should always be kept near the work area.**
In case of a fire, make sure to have equipment that has been regularly inspected installed at all times.
- **When disposing of this product, please dispose of it in accordance with the laws of your country.**

2

Outline of Equipment

2.1 Names and Roles of Parts




2.2 Structure Example of Coating Machine Installation

Air electrostatic handgun

Example of <HB6000>

For connection method of each gun, see "4 Unit Installation"



NOTE

No paint hose/air hose/connecting cable/electrostatic controller BPS130EN/diaphragm pump PD40S are attached.

⚠ WARNING

Install the control unit outside of the coating booth and at a place at least 1.5 m away from the booth opening or entrance.

2.3 Related Accessory Equipment

- The related accessory equipment and maintenance tools are necessary for the operation of this product.


Select appropriate equipment from the following according to its usage/conditions and arrange it separately.

- As for arrangement of the products and parts of the related accessory equipment, check their part No. and quantity with their equipment manuals separately.

2.3.1 Air Cap (Model: HN Series) (Separately Offered)

- A part attached to the tip of the coating machine having a function of atomizing and creating pattern by force of air.
- Select an air cap from the separate manual according to its usage.

Air cap HN series image




Air cap HN series (separately offered)

* All the HN series can be used for the common paint nozzle assembly.

2.3.2 Electrostatic Controller (BPS130EN)

- Equipment which controls high voltage application of the cascade contained in the coating machine. Also it detects abnormality and performs output in current monitoring when used.

BPS130EN outline view



BPS130EN part No. list

No.	Model	Part name	Parts No.	Input voltage	Specifications
1	BPS130EN	Electrostatic controller	52544	100 to 120 V	With base
2			52545		Without base

2.3.3 Transmission Cable

- By combining and connecting a "connecting cable" and "extension cable" between the coating machine and electrostatic controller, it can be used up to 30 m.


Connecting cable part No. list

No.	Part name	Parts No.	Specifications
1	Connection cable	2552	10 m

Extension cable part No. list

No.	Part name	Parts No.	Specifications
1	Extension cable	2549	10 m
2		2549-1	20 m

Transmission cable connection diagram



2.3.4 Air Hose (Model: AH22 Series)

- To supply air required for atomization of paint and pattern creation to the coating machine, connect it between the air regulator of the electrostatic controller and coating machine.
- A grounding wire is contained; therefore, the ground of the coating machine can also be secured through the air path and safety is improved.

Air hose part No. list

No.	Model	Part name	Parts No.	Specifications
1	AH22-5	Air hose	3403	5 m
2	AH22-10		3403-2	10 m
3	AH22-20		3403-3	20 m

2.3.5 Paint Hose

- A paint hose for sending paint from the pump to the coating machine. A flexible tube is employed to improve the handling of the gun.

Paint hose part No. list

No.	Part name	Parts No.	Specifications
1	Paint hose	3421	5m
2	Paint hose	3421-2	10m
3	Paint hose	3421-3	20m

2.3.6 Maintenance Tool Set

- Preventive maintenance of parts and repair/part replacement due to failures can be done by replacing the targeted part assembly, but this is a maintenance tool set consisting of dedicated tools for more detailed part replacement and maintenance of the cascade assembly etc. and control tools for strict torque control.
"Assembly" means a unit consisting of two or more parts.

CAUTION

If you are interested in detailed maintenance, we will provide a maintenance course.

Only the person who have attended the maintenance course specified by us, can detailed maintenance.

For information on the maintenance course, please contact our person in charge.


Maintenance tool set

No.	Part name	Parts No.	Remarks
1	Maintenance tool set	35EA	

3

Specifications

3.1 Dimensional Outline



3.2 Product Specifications

Model	HB6000
Applicable paints	Water paint
Maximum fluid pressure	0.6 MPa
Maximum air pressure	0.6 MPa
Maximum applied voltage	DC-30 kV
Operating environment	Temperature: 5 to 40°C Humidity: 40 to 80%
Mass	520 g * Including nozzle and air cap
Applicable air cap	HN400/HN800 * For details, see the separate catalog.
Electrostatic controller	BPS130EN, BPS1600
Connecting cable length	10 m * By combining it and an extension cable, it can be used up to 30 m.
Supply air conditions	Solid particle size: 0.1µm or below Dew point under pressure: 10 °C Dew point under atmospheric pressure: -17°C Residual amount of oil: 0.01 mg/m ³

3.3 Specific conditions of use

These electrostatic gun and controller shall only be used in one of the following combinations.

Certificate No.	Gun	Controller
03ATEX5417X	HB6000	BPS130EN BPS1600

NOTE

**Do not use a paint heater. Supply paint at 40°C or below.
If the temperature of paint is high, the paint hose may soften and can be disconnected.**

NOTE

**For details on the paint pressure-feed unit and paint regulator, see the instruction manuals.
The paint pressure-feed pressure should be 0.6 MPa or less.**


4

Unit Installation

Make preparations in accordance with the following procedures when starting to use the unit.

4.1 Connection of Air Source

Connect the air source to the air regulator attached to the electrostatic controller.
(Screw port diameter: PF1/4)




4.2 Connection of Grounding Wire

Be sure to connect it to the controller. For this operation, a Phillips screwdriver is required.


CAUTION

The diameter of the grounding wire of the electrostatic controller should be 3.5 mm² or more and it should be laid at a place where type D grounding (grounding resistance: 100 Ω or less) has been done.




4.3 Transmission Cable

Wipe the metal connector at the end of the connecting cable attached to the coating machine with a clean cloth, securely tighten it to the output terminal "OUTPUT" of the electrostatic controller.



Attach the cable to the gun by securely tightening it with a hex. 17 mm spanner. After attaching it, prevent loosening with a stopper. If the attachment position cannot be adjusted, do not tighten it forcibly. Loosen the nut and attach it so that the stopper surface will stick to the hex. flat part.



CAUTION

Damage of the unit may occur.

Do not tighten the connecting cable too tightly. Be sure to prevent loosening with a stopper. Excessive tightening by tools may damage the cable connector.


CAUTION

Disconnection of a cable may occur.

When bundling the connecting cable, air hose and paint hose with tape and the like, loosen them slightly so that pull force will not be applied to the cable. If you use it with the cable pulled, it may lead to disconnection. For details, see "4.6 Binding of Connecting Cable and Precautions for Use".

4.4 Connection of Air Hose

Connect the end cap of the black air hose to the nipple at the lower end of the gun grip (next to connecting cable). Then connect the other end connector to "AIR OUT" of the electrostatic controller and tighten it. (Screw port diameter: PF1/4) A spanner of 17 mm is required for this operation.



CAUTION

Damage of the unit may occur.


When tightening an air hose or paint hose to the gun, be sure to use two spanners and do not apply excessive force to the gun. Also remove and attach it so that the spanner will not touch the cable connector.

NOTE

If the length of the air hose is 10 m or more, by using a 3/8 air hose, atomization of paint will be improved. If a joint bush (3259-001) is attached, it will be a screw port diameter of PF3/8.

4.5 Connection of Paint Hose

Connect the end cap of the paint hose to the lower end of the gun grip (in front of connecting cable) and attach the other end paint hose connector to the paint pressure-feed unit (screw port diameter: PF1/4).




When paint hose is retighten, hook tools (wrench) to width Across flat.

Please be carried out with care prevent from scratch the grip-end surface.

4.6 Bundling of Connecting Cable and Precautions for Use

CAUTION

1. To prevent reduction in strength and service life of the connecting cable, be sure to observe the following for bundling of connecting cable of the electrostatic gun.
 - (1) Do not bind connecting cable within a range of approximately 70 cm from the electrostatic gun handle.
 - (2) Bind the connecting cable while securing allowance of the connecting cable for the air hose and paint hose so that the connecting cable will not be strongly bent or pulled when aiming the electrostatic gun upward, downward, left and right.
 - (3) Loosely bind the cable outside a range of 70 cm from the electrostatic gun handle at intervals of 5 cm with resin banding bands (insulok) and plastic tape not by tightening it too tightly. In particular, do not wind plastic tape and wide spiral tubes seamlessly. The wound part will be a rod-like shape and its both ends will be broken, which leads to disconnection or damage of the connecting cable and hose.




2. Operate the electrostatic gun and bind the connecting cable so that the connecting cable, air hose and paint hose will not be forcibly bent or strongly pulled during painting. Strength may be lowered and disconnection may occur.
3. Be careful not to step on the connecting cable. In particular, if you step on it on metal floor grates, it may be disconnected.
4. Do not wind plastic tape only on the connecting cable (especially vicinity of electrostatic gun connector) seamlessly for reinforcement and prevention of contamination. Strength may be lowered and disconnection may occur.
5. Do not immerse the connecting cable in the solvent or paint for a long time. If it is immersed for a long time, its strength and service life will be reduced significantly.
6. After cleaning the connecting cable, be sure to wipe off the solvent attached to the surface or blow it with air.
7. Do not use metal banding bands. Static electricity accumulates and you may get a shock.

4.7 Installation of Air Cap

(1) Fix the air cap to the nozzle by hand.

At this time, be careful so that the electrode pin will not be bent due to the air cap.


Also tilt the gun tip downward so that thinner or solvent will not enter the gun.



(2) Pass the retaining nut assembly through the outside of the air cap.

[1] Tighten the retaining nut assembly until it is securely tightened, and then adjust the angle direction of the air cap to the direction of pattern creation.

[2] Tighten the retaining nut assembly more strongly until the air cap is fixed.



CAUTION

Personal injury or damage of the electrode pin may occur.
When attaching the air cap to the gun, do not touch the electrode pin.

CAUTION

Damage of the unit may occur.
Since this is a resin product, the nozzle attachment joint inside diameter screw may be damaged if tightened too much. Take sufficient care when removing or attaching it.


5

Check before Coating Operation


Before a coating operation, check the coating machine in accordance with the following procedure.

5.1 Operation Check at High Voltage

(1) Open the ball cock of the electrostatic controller and adjust the air supplied to the gun to 0.3 to 0.4 MPa with an air regulator. Then check that there is no air leakage from the connection of the hose.




(2) Turn on the power switch of the electrostatic controller while holding the grip of the gun. If it is normal, a green lamp will be lit on the controller. At this time, no high voltage is applied to the tip of the gun.



(3) Pull the trigger of the gun. If air is discharged from the nozzle, the air flow switch contained in the electrostatic controller will be activated, the high voltage indicator (green) of the controller will be lit and high voltage will be generated. Also the H.V. lamp (red) on the back of the gun body will be lit. When the red lamp is lit, high voltage is applied to the tip of the gun.

High voltage indicator "H.V." = Green light



WARNING

Personal injury or accidents may occur due to electric shock.
Do not touch the air cap, nozzle and electrode pin when high voltage is applied.

CAUTION

When an inspection is completed, turn off the power switch of the electrostatic controller.

5.2 Mixing of Paint

Since this unit can obtain an electrostatic effect with almost all synthetic resin except some paints, it is not necessary to mix paints specially.

CAUTION

In the case of HB6000, only water paint can be used for electrostatic coating.

CAUTION

Use paint and solvent whose flash point is higher than the room temperature by 5°C or more and be sure to activate the ventilation system.

NOTE

If you have any questions about compatibility of the gun, system and paint, please consult us.

6

Coating Preparation

Before a coating operation, make preparations for coating in accordance with the following procedure.

⚠ CAUTION

Check that the power switch of the electrostatic controller is turned off.


(1) Put paint in the paint feeder.

When this coating machine is used, the general standard viscosity is approximately 45 to 100 sec/FC#4, but it is not necessarily limited depending on various conditions such as the type of paint and solvent, shape of the product to be coated and thickness of the coating film.

(2) Operate the paint feeder to feed the paint to the gun.


Operate the pump at a low pressure (approximately 0.1 MPa) with the air regulator for the pump and suck the paint.

Adjust the paint regulator attached to the paint outlet of the pump so that the pump pressure will be increased to approximately 0.2 to 0.3 MPa.




(3) Discharge paint through the gun tip.

Discharge paint through the gun tip by pulling the trigger with air not supplied to the gun. If air is remained in the paint hose, it causes shortness of breath when paint is discharged; therefore, keep discharging paint until the air in the hose has been removed.




The paint discharge rate is increased by turning the paint adjuster at the back of the gun to the left. If it is tightened to the right, the rate will be decreased and the discharge will be stopped.




(4) Check the atomization state of the paint discharged from the gun.

Adjust the pressure of the air supplied to the gun to 0.2 to 0.3 MPa and atomize the paint by pulling the trigger. Adjust the air pressure according to the air cap used.



(5) Adjust the pattern width of the atomized paint.

Adjust the pattern width with the pattern valve on the left side of the gun. If you turn it to the left, the pattern will be broadened; to the right, narrowed. Adjust it according to the shape of the product to be coated.



WARNING

Check that there is no air leakage when the connection of the air hose and trigger are returned. If the power of the controller is turned on when air is discharged, high voltage will be generated even when a coating operation is not performed.

⚠ CAUTION

Before performing a coating operation, check that the grounding resistance of the product to be coated is within the range of the following values.

- If product to be coated is metal: 1 kΩ or less
- If product to be coated is resin: 1 MΩ or less

● Start of Coating Work

(1) Turn on the power switch of the electrostatic controller.

⚠ CAUTION


Before turning on the power switch of the electrostatic controller, check the grounded condition of the grounding wire connected to the controller and product to be coated.

(2) Pull the trigger of the gun to start coating work.

Adjust the voltage of the electrostatic controller according to the condition of the product to be coated.

When it is adjusted as shown in the following figure for the maximum set voltage of the equipment used, the voltage indicated at the lower part of the level lit is the set voltage.

* Following figure: When HB6000 is used Set voltage = -30 kV



⚠ WARNING

Sparks may be generated, possibly resulting in fire.

Do not allow the electrode pin of the gun tip to contact a product to be coated.

If the electrode pin approaches the grounded object, the electric potential of the pin will be controlled to be lowered automatically. However, if the approach speed is fast, sparks may be generated.

Keep the gun, paint hose and connecting cable clean so that there will be no contamination such as paint. Also always be careful so that they will not be damaged due to mechanical shocks.

8.1 Measures After Operation is Completed

When suspending or finishing the coating operation, use the following procedure.

8.1.1 In Case Where Operation is Resumed Within 24 Hours

(1) Turn off the power switch of the electrostatic controller.


While holding the grip of the gun, turn off the power switch of the controller with the other hand.

WARNING


Sparks may be generated, possibly resulting in fire.

Never leave the gun on a workbench or the ground with the power switch of the electrostatic controller turned on.


(2) Adjust the pressure of air supplied to the gun to 0 MPa.




(3) Adjust the drive air pressure of the paint pressure-feed unit to 0 MPa.



(4) Discharge paint through the gun tip to release the residual pressure.




(5) With the trigger opened to remove the residual charge, gently ground the electrode pin at the nozzle tip.



(6) Remove the retaining nut by turning to the left and air cap too.

When removing the air cap, tilt the gun tip downward so that thinner or solvent will not enter the gun.



⚠ CAUTION

When removing the air cap, be careful not to drop it.
If dropped, it may be damaged.

⚠ WARNING

Personal injury or accidents may occur.
When removing the air cap, do not touch the electrode pin.

 **CAUTION**

Damage of the retaining nut, nozzle and unit may occur.

When removing the retaining nut, be sure to turn it by hand.

If you use a tool, damage may occur.

(7) Wipe off dirt such as paint mist attached to the gun and air cap with a cloth impregnated with cleaning solvent.

 **CAUTION**

When cleaning the gun and air cap, do not use a hard brush such as a metal brush. Their surfaces may be damaged and their performance may be impaired.

 **CAUTION**

When a coating operation is not performed, close the paint adjuster of the gun to prevent paint from being discharged due to a careless operation.

 **CAUTION**

When cleaning the nozzle and air cap, always tilt the gun tip downward so that solvent will not enter the coating machine. After the cleaning, pull the trigger to release air to discharge the entered solvent.

 **CAUTION**

After cleaning or an operation, do not allow the gun, power cable, hose, etc. to be immersed in solvent.

Electric and electronic circuits are contained in the gun and a structure is employed where solvent does not enter when a normal usage method is used. However, if they are immersed in solvent for a long time, their durability will be decreased, which may cause failures.

 **CAUTION**

When using chemically hardened paint such as two-component paint or paint that settles easily, clean it based on "8.1.2 In Case Where Operation is Not Performed for 24 Hours or More" each time an operation has been completed.

8.1.2 In Case Where Operation is Not Performed for 24 Hours or More

- (1) Turn off the power switch of the electrostatic controller.
- (2) Adjust the pressure of air supplied to the gun to 0 MPa.
- (3) Extract the suction pipe of the paint pump from the paint container.
- (4) Drive the paint pump at a low pressure (approximately 0.1 MPa) and discharge the paint in the pump from the return side to the paint container.
- (5) Discharge the paint remaining in the hose and gun through the gun tip by pulling the trigger of the gun.
- (6) Suck the cleaning solvent through the suction pipe, discharge it from the return side to the cleaning wastewater container and repeat the cleaning until the inside of the pump is cleaned.
- (7) Discharge the solvent through the gun tip to clean the hose and inside of the gun.
- (8) Stop the pump and pull the trigger of the gun to release the residual pressure through the gun tip.
- (9) Turn the retaining nut to the left to remove the air cap.
- (10) Wipe off dirt such as paint mist attached to the gun and air cap with a cloth impregnated with cleaning solvent.
- (11) With the trigger of the gun pulled, put a dedicated spanner on HEX of the nozzle and turn it to remove the nozzle.

It is recommended to allow the cleaning fluid to remain in the circuit after cleaning to prevent fixation of paint remaining in the paint circuit.

CAUTION

Damage of the nozzle and needle may occur.

Be sure to remove the nozzle with the trigger of the gun pulled.

The seat surfaces of the nozzle and needle will be damaged and failures of the seat may occur.

CAUTION

Damage of the nozzle may occur.

When removing the nozzle, be sure to use the attached dedicated spanner.

Be careful not to drop it.

- (12) Immerse the nozzle in cleaning solvent and blow off the dirt with compressed air.

CAUTION

When cleaning the nozzle, do not poke at it with metal such as wire.

Also do not use a metallic brush and the like. Its performance may be impaired due to enlargement of hole diameter and scratches.

CAUTION

Only after 10 seconds have passed since the power switch of the electrostatic controller is turned off, clean the gun. Ninety percent or more of fire accidents due to the electrostatic coating machine have occurred when the nozzle etc. is cleaned. When cleaning the nozzle etc., be sure to turn "OFF" the power switch. Keep a fire extinguisher at your hand in case of fire accidents.

CAUTION

If a problem occurs during an operation, immediately turn "OFF" the power switch of the electrostatic controller and lower the pressure of the air and paint supplied to the gun to 0 MPa.

CAUTION

Always hang the gun on the gun hanger fixed to a wall.

CAUTION

Be careful so that shocks such as falling will not be applied. Plenty of resins are used for HB6000 for weight saving. They are designed taking into account strength but may be damaged due to shocks.

- (13) As for disposal of cleaning wastewater, recover and recycle it using a solvent recovery system or dispose of it through a contracted industrial waste processor in accordance with the laws.

8.2 Periodic Inspection

In order to fully exercise the performance of this equipment, perform periodical inspection according to the following table.

The inspection timings are only shown as a guide and may vary depending on the conditions of use.

WARNING

Personal injury or accidents may occur due to an unexpected operation of the coating machine.

When conducting a periodic inspection, turn off the power of the electrostatic controller and release the pressure of the air and paint.

Item	Action	Period
Check external appearance of the gun body	If there is paint dirt, saturate a soft cloth or brush with cleaning solvent and wipe it off.	1 day
	If there is damage, replace with a new one.	
Check for air cap paint dirt	If there is paint dirt, saturate a soft cloth or brush with cleaning solvent and wipe it off.	
Check for electrode paint dirt	If there is paint dirt, saturate a soft cloth or brush with cleaning solvent and wipe it off.	
Check for clogging of air spray hole of air cap	After immersing in cleaning solvent, remove by blowing air.	
	If cannot be removed, replace with a new one.	
Check for scratches and dents around paint outlet of nozzle	If there are scratches or dents, replace with a new one.	
Check for clogging of paint spray hole of nozzle	After immersing in cleaning solvent, remove by blowing air.	
	If cannot be removed, replace with a new one.	
Check paint seat of nozzle	Inject cleaning solvent to clean paint path and nozzle of gun.	
	If the problem is not solved, replace the nozzle or needle electrode with a new one.	
Check ground electrode	If the distance from the paint spray hole of the nozzle is less than 3.5 mm with the trigger not pulled, replace with a new one.	
Check connecting cable	If there is damage, replace with a new one.	
Check air leakage from trigger	If there is air leakage, replace the air seat.	1 month
Check paint dirt in paint tube	If there is paint dirt, inject cleaning solvent to clean it.	
	If adhered paint cannot be removed, replace with a new one.	
Check paint valve	If the discharge rate cannot be adjusted, replace with a new one.	
Check pattern air valve	If the spray pattern cannot be adjusted, replace with a new one.	
Check for entrance of paint/solvent into electrode assembly	If there is entrance of paint and solvent, replace with O-ring or a new one.	

NOTE

For parts replacement method, see "11. Parts Replacement Method".

 **CAUTION**

Do not disassemble the gun unnecessarily except for the case of a failure. To secure electric insulation of the gun and the sealing function, disassemble it only when the parts are replaced due to a failure.

 **CAUTION**

The upper rear part of the gun may be warmed due to the heat of the high-voltage generator, but this is not a problem.

 **CAUTION**

When using a container for cleaning, be sure to ground a conductive container.

8.3 Consumables

Prepare spare parts according to the conditions of use, referring to the rank classification in the following consumables list.

Rank classification	Part name	Part No.	Component assembly	Publishing page
A	Paint nozzle assembly	15F7	Core unit	41
	Ground electrode assembly	1705-1	Core unit	41
B	Packing assembly	14E8	Core unit	41
	Straight tube	30E-0001	Straight tube set	44
	Sleeve	145A-005	Straight tube set	44
	U seal	373-0008	Core unit	41
	U seal	3737-0009	Core unit	41
	Ring seal	373-0010	Retaining nut assembly	44
C	Gun hook	12A1-002	HB6000	40
	Pattern valve	14C9	HB6000	40
	Paint adjuster	14E1	HB6000	40
	Stopper	14C3-003	Grip end assembly	42
	Air valve assembly	14C6	Core unit	41
	Needle assembly	14E7	Core unit	41
	Electrode assembly	14E9	Core unit	41
D	Packing	14F9-003	Core unit	41
	O-ring	130-6007	Pattern valve	43
	O-ring	101-6005	Grip end assembly	42
	O-ring	130-6010	Paint adjuster	43
	O-ring	130-6030	Grip end assembly	42
	O-ring	130-7010	Cascade assembly	42
	O-ring	130-9012	Paint nozzle assembly	43
	O-ring	130-9010	Electrode assembly	43

Rank A: Daily consumables




Rank B: Medium-term consumables

Rank C: Parts which may be damaged/lost when used

Rank D: Parts required to be replaced when disassembled

Accessory tool

35CF

Dedicated flat spanner Part No.: 35CF-001	Box spanner Part No.: 337-0056	Bamboo brush Part No.: 337-0006
		

9

Paint Problems and Solutions

Depending on the situation of a paint problem, several problematic phenomena and causes may occur at the same time.

Problematic phenomenon	Cause	Countermeasure
1. Atomization of spraying is bad	(1) Atomizing air pressure is too low.	(1) Set atomizing air pressure to rather high.
	(2) Paint discharge rate is too high.	(2) Set discharge rate to rather low or atomizing air pressure to rather high.
	(3) Viscosity is too high.	(3) Decrease paint viscosity.
	(4) Nozzle tip pin is bent.	(4) Replace ground electrode assembly.
	(5) Nozzle is damaged.	(5) Replace paint nozzle assembly.
	(6) Solvent is inappropriate.	(6) Please consult us or paint manufacturer.
2. Much paint splashes back	(1) Spraying distance is too long.	(1) Spraying distance should be within 150 to 200 mm.
	(2) Atomizing air pressure is too high.	(2) Adjust atomizing air pressure to rather low.
	(3) Grounding of product to be coated is inappropriate.	(3) Ground firmly.
	(4) Exhaust velocity is too slow.	(4) Set exhaust velocity to rather fast.
3. Coating efficiency is low	(1) Grounding of product to be coated is poor.	(1) Clean paint attached to hanger and ground perfectly.
	(2) Atomizing air pressure is too high.	(2) Adjust atomizing air pressure to appropriate pressure.
	(3) Spraying distance is too long.	(3) Spraying distance should be within 150 to 200 mm.
	(4) Applied voltage is low.	(4) Increase output with output voltage adjustment switch of electrostatic controller.
	(5) Booth supply and exhaust rate is too high.	(5) Adjust booth supply and exhaust rate to rather low.
4. Paint is attached to nozzle, which causes roughening, or string like particles are created on product to be coated	(1) Viscosity of paint is high.	(1) Decrease viscosity of paint.
5. Particles are created on coated surface	(1) Atomization of spraying is bad.	(1) See Section 1 in this chapter "Atomization of spraying is bad".
	(2) There is plenty of dirt in coating booth and dirt is attached to coated surface.	(2) Install dust-proof filter on suction part of coating booth to remove dirt on coated surface.
	(3) Atomizing air is dirty.	(3) Clean or replace filter at air passage.
	(4) Pigment dispersion of paint is bad.	(4) Review solvent or filter paint well.
6. Orange peel (dapple, pockmark) is	(1) Temperature is high in coating booth or evaporation rate of solvent is high.	(1) Adjust temperature or replace with solvent whose evaporation rate is low.

Problematic phenomenon	Cause	Countermeasure
created	(2) Temperature of product to be coated is too high.	(2) To lower temperature of product to be coated, adjust drying furnace.
	(3) Supply and exhaust rate is too high.	(3) Adjust to 0.5 to 1.0 m/sec on product surface to be coated.
7. Cissing occurs	(1) Cleaning of product to be coated is insufficient.	(1) Clean or defat sufficiently.
	(2) Atomizing air is dirty.	(2) Clean or replace filter at air passage.
	(3) Exhaust of baking furnace is inappropriate.	(3) Exhaust air sufficiently.
8. Paint trickles down on coated surface	(1) Coating film is too thick.	(1) Decrease paint discharge rate or increase operation speed of hand gun.
	(2) Viscosity of paint is too low.	(2) Increase paint viscosity.
	(3) Evaporation rate of solvent is low.	(3) Replace with solvent whose evaporation rate is high.
9. Coating film is translucent	(1) Paint discharge rate is low.	(1) Adjust paint discharge rate and consider operation speed of hand gun and recoating.
	(2) Viscosity of paint is too low.	(2) Increase viscosity.
10. Pin holes (small holes) are created	(1) Atomizing air is dirty.	(1) Clean or replace filter at air passage.
	(2) Temperature of product to be coated is high.	(2) Lower temperature.
	(3) Drying of undercoating is insufficient.	(3) Dry sufficiently.
	(4) Setting time is short.	(4) Take sufficient setting time.
11. Whitening occurs	(1) Temperature and humidity are high inside/outside coating booth.	(1) Check air conditioner.
	(2) Selection of solvent is inappropriate.	(2) Please consult us or paint/solvent manufacturer.
12. Foaming occurs	(1) Atomizing air is dirty.	(1) Clean or replace filter at air passage.
	(2) Drying after wet rubbing is insufficient.	(2) Dry sufficiently.
	(3) Coating film is too thick.	(3) Set paint discharge rate to rather low.
	(4) Evaporation rate of solvent is too high.	(4) Replace with solvent whose evaporation rate is low.
	(5) Temperature of baking furnace is too high.	(5) Adjust temperature to appropriate value.
13. Pattern shape is not good	(1) Paint and dirt are attached to atomizing air and paint spray hole of nozzle.	(1) Clean well with thinner and bamboo brush and filter paint.
	(2) Viscosity of paint is high.	(2) Decrease viscosity.
	(3) Nozzle tip is damaged.	(3) Repair or replace.
	(4) Pattern adjustment is bad.	(4) Adjust with pattern adjustment knob.
	(5) Nozzle attachment is bad.	(5) Check paint nozzle assembly is not loosened and attach air cap.
14. The amount of paint sprayed is not stabilized.	(1) The needle stroke length is short. * It is recommended that the needle stroke length be 1 mm or more for use.	(1) Decrease the paint injection pressure and increase the needle stroke length.
		(2) Install an orifice etc. in the paint path and increase the needle stroke length.

Depending on the situation of a paint problem, several problematic phenomena and causes may occur at the same time.

Phenomenon of failure	Cause	Countermeasure
1. Atomization of spraying is not stable and stops during operation	(1) Paint nozzle assembly is not sufficiently tightened.	(1) Firmly tighten the paint nozzle assembly.
	(2) Seat surface of paint nozzle assembly is damaged.	(2) Replace the paint nozzle assembly.
	(3) Air is included in paint.	(3) Check for paint supply system.
	(4) Spraying amount is extremely low.	(4) Increase the spraying amount or lower the atomization pressure.
2. Spraying amount of paint becomes smaller	(1) Abnormality in pressure feeding of paint	(1) Check for paint supply system such as paint pump and paint regulator.
	(2) Paint solid or dust are clogged at the paint seat.	(2) Clean the paint seat.
	(3) Paint solid or dust are stuck at the paint nozzle assembly.	(3) Remove the paint nozzle assembly and clean it.
3. Paint leaks from the nozzle	(1) Paint solid or dust are clogged at the paint seat.	(1) Clean the paint seat.
	(2) Wear or crack at paint seat	(2) Replace the paint nozzle assembly or ground electrode assembly.
	(3) Weakening of spring at paint seat	(3) Replace the spring.
	(4) Pressure feeding of paint is too high.	(4) Lower the pressure feeding.
4. Paint leaks from the U seal portion	(1) Wear of packing assembly	(1) Replace the packing assembly.
	(2) Insufficient tightening of packing assembly	(2) Install the packing assembly properly.
	(3) Damage to the O ring of packing assembly	(3) Replace the O ring of packing assembly.
5. Air leaks from the nozzle even if the trigger is returned	(1) Dust is clogged at the seat portion of air valve assembly	(1) Clean or replace the air valve assembly.
	(2) Wear of air valve assembly	(2) Replace the air valve assembly.
	(3) Weakening of spring	(3) Replace the spring.
6. Air leaks from the air adjuster	(1) Wear or breakage of O ring	(1) Replace the O ring.
7. Sparks occur from the electrode assembly	(1) Cascade assembly is damaged.	(1) Replace the cascade assembly.
	(2) Electrode assembly is damaged.	(2) Replace the electrode assembly.
8. Warning buzzer of control unit sounds	(1) Paints are attached to the barrel.	(1) Clean the barrel.
	(2) Paints are attached to the paint tube.	(2) Clean the paint hose.
	(3) Paints are attached to the electrode assembly.	(3) Clean the electrode assembly.

Phenomenon of failure	Cause	Countermeasure
	(4) Paints are intruded into the electrode assembly.	(4) Remove the electrode assemblies and clean them together with barrel.
	(5) Paints are attached to the air cap or retaining nut.	(5) Remove the electrode assembly and retaining nut.
	(6) There is water in the air path inside the barrel.	(6) Properly drain the water in the air line. Turn off the electrostatic controller, pull the trigger and remove the air, and spray out the water in the air path.
	(7) Paint leaks due to the damage or wear of packing assembly.	(7) Replace the packing assembly or O ring with a new one.

 **CAUTION**

Do not perform repair other than the method indicated in this Operation and Maintenance Manual.

Follow the procedures below when replacing or repairing parts.

⚠ WARNING

Personal injury or accidents may occur due to an unexpected operation of the coating machine.


Before replacement and repair of parts, be sure to turn off the compressed air supplied to the gun, turn off the power of the electrostatic controller, discharge the paint in the paint passage and clean it.

11.1 Replacement of Air Cap


(1) In accordance with "4.7 Installation of Air Cap" in Chapter 4 "Unit Installation", remove and replace it.

11.2 Replacement of Paint Nozzle Assembly

(1) Replace it by stopping the paint pump, using a flat spanner (accessory tool) while pulling the trigger with the residual pressure released and removing the nozzle.



(2) If the O-ring (130-9012) is damaged when removing the paint nozzle assembly, replace it.




⚠ CAUTION

Confirm are not paint clinging, scar and dirt in the screw of the barrel and the paint nozzle when install the paint nozzle. Becomes impossible for paint to leak, and to remove the paint nozzle due to the screw and dirt.

11.3 Replacement of Ground Electrode Assembly

- (1) Remove and replace it by holding the ground electrode assembly with fingers with the trigger pulled. Also when attaching it, tighten it by holding the ground electrode assembly with fingers with the trigger pulled. Do not tighten it too tight because it is a resin part.


1705-1: Needle electrode assembly



11.4 Replacement of Packing Assembly


- (1) Remove and replace the packing assembly using the box spanner (accessory tool) with the ground electrode assembly removed. When attaching the packing assembly, do not tighten it too tight because it is a resin part. As a tightening guide, tighten it by about 1/4 rotation from a hardened state (start of effectiveness of O-ring).

* Recommended tightening torque = 50cN·m



- (2) When cleaning the inside of the packing assembly, clean the entire part with thinner without disassembling the inside, and after cleaning, completely dry it by blowing air.

* Since the packing part is set with controlled load, do not remove it. If the packing part is damaged, replace it with the packing assembly.




11.5 Replacement of Needle Assembly


(1) Remove the hex. socket low head bolt fixing the trigger using a hex. wrench of hex. 2 mm and extract the trigger downward.

In this case, to prevent the collar holding the hex. socket low head bolt from being dropped/lost, take loss prevention measures.

360-0108: Hex. socket low head bolt



12A1-004: Collar




Hex. wrench: Hex. 2 mm

12A1-001: Trigger

(2) Extract and replace the needle assembly from the barrel with the needle electrode assembly and packing assembly removed as shown in the figure.

In this case, to prevent the spring from being dropped/lost, take loss prevention measures.




14F9-004: Spring

14E7: Needle assembly

11.6 Replacement of Pattern Valve

(1) Remove and replace the pattern valve using a flat spanner (accessory tool) with the pattern valve fully opened.

14C9: Pattern valve




35CF-001: Flat spanner


Loosen

Tighten

Flat spanner position




- (2) When removing the pattern valve, be sure to replace the O-ring (130-6007).
It is recommended to apply white petrolatum to the screw part and O-ring part when attaching it.




11.7 Replacement of Paint Adjuster

- (1) Remove and replace the paint adjuster using a flat spanner (accessory tool).




- (2) When removing the paint adjuster, be sure to replace the O-ring (130-6010).
It is recommended to apply white petrolatum to the screw part and O-ring part when attaching it.



11.8 Replacement of Air Valve Assembly


- (1) Extract and replace the air valve assembly using long nose pliers by extracting the spring with the paint adjuster removed.




- (2) Installation the paint adjuster after installs air valve assembly and tighten in addition after completely close. The seat becomes harmonize, and the seat improves.
Completely open the paint adjuster, turn on air, and confirm whether air leaks gun head.

11.9 Replacement of Grip End Assembly


- (1) Loosen the two hex. socket fall prevention screws at the grip end part using a hex. wrench of hex. 3 mm.
* Recommended tightening torque = 100cN·m



- (2) Loosen the hex. socket fall prevention screws and slowly extract the grip end assembly from the body assembly. If it is extracted swiftly, the inside wires may be disconnected.




- (3) When removing the grip end assembly, be sure to replace the O-ring (101-6005/130-6030).




11.10 Replacement of Gun Hook

- (1) Remove the hex. socket bolt (03-50310) fixing the gun hook using a hex. wrench of hex. 2.5 mm and extract the gun hook slide-fixed to the body assembly in the direction of the arrow to remove and replace it.




11.11 Replacement of U Seal (373-0008)

(1) Replace the U seal by removing the cover slide-fixed to the barrel in the direction of the arrow with the trigger and needle assembly removed. Since the U seal is firmly fixed to the barrel, remove it with a flat-blade driver etc. If removed, the U seal may be deformed/damaged, so be sure to replace it.




(2) Attach the U seal by pressing the cover with a hex. wrench etc.

* If only the U seal is pressed, the lip part may be deformed or damaged.




11.12 Replacement of Paint Tube

(1) Loosen the cover using a spanner of hex. 22 mm.



(2) Loosen the two nuts using a spanner of hex. 14 mm to replace the paint tube.


When replacing the paint tube, be sure to replace the two sleeves too to prevent paint leakage.



11.13 Replacement of Electrode Assembly


(1) Remove the electrode assembly from the barrel by rotating it.

Be sure to remove it by hand, not using a tool.



(2) Attach the electrode assembly to the barrel.


Replace the O-ring of the electrode assembly and push it to the position where it sticks to the barrel, then rotate it until a clicking sound is heard.



12.1 HB6000

HB6000

12A5




No.	Part No.	Part name	Quantity	Remarks
1	12A1-001	Trigger	1	
2	12A1-002	Gun hook	1	
3	12C5-003	Plug	1	
4	12A1-004	Collar	2	
5	03-50310	Hex socket bolt	1	
6	360-0108	Hex socket low head bolt	2	

No.	Part No.	Part name	Quantity	Remarks
7	14C9	Pattern valve	1	
8	14E1	Paint adjuster	1	
9	14F1	Straight tube set	1	
10	Nil			
11	-	Core unit	1	*
12	35CF	Accessory tool	1	

* Can not order with core unit only.

12.2 HB6000 Core Unit

Core unit



No.	Part No.	Part name	Quantity	Remarks
1	14F9-001	Cover	1	
2	14F9-002	Contact	1	
3	14F9-003	Packing	1	
4	14F9-004	Spring	1	
5	14F9-005	Spring	1	
6	14F9-006	Spring	1	
7	373-0008	U seal	1	
7	373-0009	U seal	1	
9	14C2-3	Body assembly	1	For repair
10	14C3	Grip end assembly	1	

No.	Part No.	Part name	Quantity	Remarks
11	14E5	Cascade assembly	1	
12	14E6	Barrel	1	
*13	14C6	Air valve assembly	1	
*14	14E7	Needle assembly	1	
15	14E8	Packing assembly	1	
16	15F7	Paint nozzle assembly	1	
*17	1705-1	Ground electrode assembly	1	
18	1707	Retaining nut assembly	1	
19	14E9	Electrode assembly	1	

Items marked with * are the parts, replace with assembly parts.


12.3 Replacement Parts

The following are the replaceable parts in the parts assembly.
Parts not indicated should be replaced in assembly units.

Body assembly

14C2-3

360-0107
: Hex socket fall
prevention bolt



Grip end assembly

14C3

360-0107
: Hex socket fall
prevention bolt

101-6005
: O-ring


130-6030
: O-ring

360-0107
: Hex socket fall
prevention bolt

03-70308
: Hex socket bolt

14C3-001
: Grip end A

14C3-003
: Stopper




Cascade assembly

14E5

130-7010
: O-ring


14C4-001
: Spring



Barrel


14E6

360-0107
: Hex socket fall prevention bolt




Packing assembly

14E8




Pattern valve

14C9




Paint adjuster

14E1




Electrode assembly

14E9




Paint nozzle assembly

15F7




Plug

12C5-003



Retaining nut assembly

1707




373-0010
: Ring seal

* When Ring seal is removed
from Retaining nut,
Please replace to new one.

Straight tube set

14F1



14E2-007
: Packing

14E2-003
: Joint

14E2-001
: Cover

130-6005
: O-ring

30E-0001
: Straight tube

145A-004
: Nut

145A-005
: Sleeve

ASAHI SUNAC CORPORATION (the “Company”) shall provide the original purchaser (the “Purchaser”) with warranty service for a period of one (1) year from the date of purchase of the product, as follows:

- Should you find defects in design or workmanship with regard to parts, ship them back to the Company, with freight prepaid. The Company shall repair or replace the parts free of charge and reimburse the freight charges, provided that, as a result of an inspection and investigation of the parts conducted by the Company, the defects are deemed to be attributable to the factors within the Company’s responsibility.
- In the following cases, free after-sales service is not provided.
 1. Failure resulting from an inappropriate method of installing this equipment.
 2. Failure resulting from a use method not conforming to this instruction manual or mishandling.
 3. Failure resulting from insufficient maintenance management of this equipment and incorrect handling such as non-conformance to the procedures specified in this instruction manual.
 4. Failure resulting from unauthorized alteration or structure change of this equipment without the Company’s consent.
 5. Failure due to force majeure such as earthquake, disaster, flood disaster or lightning.
 6. Warranty for consumables worn or deteriorated even in the case where this equipment is used correctly.
 7. Repair after the machine has been used outside Japan, and shipping cost.
 8. In addition to the above, failure due to circumstances beyond our control.
- As for items such as parts purchased by the Company from another manufacturer, the warranty of that manufacturer shall apply.
- As for any parts deemed to be defective, the Company shall not be held liable for any expenses beyond the provision of repair or replacement parts free of charge.
- The Company shall not be held liable for any damage to the Purchaser caused by factors not attributable to the Company, such as misuse of product, etc.

【MEMO】

-
- When a transfer of title of this equipment takes place, please see to it that this Operation and Maintenance Manual is handed over to the new owner.
 - This equipment is manufactured in compliance with the Laws and Regulations of Japan.
In the rare eventuality of this equipment being used outside Japan, compliance with the safety standards of the relevant countries is of course mandatory.
-

28th Edition: August 4, 2025

ASAHI SUNAC CORPORATION

HEAD OFFICE

5050, SHINDENBORA, ASAHIMAE-CHO,
OWARIASAHU, AICHI PREF. 488-0852, JAPAN
PHONE +81-561-52-0717 FAX +81-561-54-8847

URL : www.sunac.co.jp
E-mail : ctrd01@sunac.co.jp

Sales office



English



Chinese

28th Edition: August 4, 2025